FIG 1



Options
Back

FIG 2



UP
S_LEFT
S_RIGHT
LEFT
SEL
RIGHT
DOWN

FIG 3


Jobline
www.mtv3.fi
smilmer
msn
w.ellos.fi

FIG 4


Jobline.fi
Options
Back

FIG 5


Options
Back

FIG 6


Options
Back

FIG 7


Options
Back

FIG 8


Options
Back

FIG 9



Parallel Port Complete

The Basics

FIG 10



Parallel Port Complete

For all you ever wanted to know about the parallel port, order a copy of ***Parallel Port Complete***. Read Chapter 1 on-line

The Basics

- Jan's Parallel Port FAQ has answers to frequently asked questions about using, interfacing, and programming the parallel port in all of its modes. Last update: 4/17/99.
- The parallel port FAQ . Basics about the parallel port and how to use it, by Zhahai

FIG 11



09945813.040301





FIG 12

09845518.040301



FIG 13

FIG 14



FIG 15


NetWork
Nokia
AloiteJaPatentti
Bgr_work
Cc-rider
Lookman
Dogu
Hard
Soft
Terminal



```
⊟ at
  ⊟ Apuohj
    ⊞ Bmp
    ⊞ hexedit
    ⊞ Pfe
      pkware
      Winmod
  ⊞ Bat
  ⊞ Book
  ⊞ Economy
  ⊞ Eppu
    kartta
  ⊞ Kuvat
  ⊞ Kämppä
  ⊞ MyConfigs
  ⊞ NetWork
  ⊟ Nokia
      AloiteJaPatentti
    ⊟ Bgr_work
      ⊞ Cc-rider
      ⊟ Lookman
          Dogu
          Hard
          Soft
        ⊞ Terminal
      ⊞ Neftis
        Nohau
      ⊞ Protopcb
      ⊞ Spec2cod
    ⊞ Expence
    ⊞ lectures
    ⊞ nmp
    ⊞ ntc
    ⊞ Timemana
  ⊞ OldThings
  ⊞ Projects
  ⊞ puhelinLuettelo
```

```
Name
dilbert19991228696 6.gif
epi01-1.rm
epi01-2.rm
file_id.diz
flnwh885.zip
fwsetup.exe
gocopy.exe
Language.dat
Layout.bin
mame035b_fix.zip
midtown_exe.zip
Mips.com
moslo.com
moslo132.zip
nokia_cebit2000.pdf
Os.dat
palupd.exe
pankki.bmp
pieces.bmp
Prophecy.avi
Secret~1.gid
Setup.exe
Setup.ini
Setup.ins
soundcard4297amr.pdf
Wc.exe
wc3script.doc
Wcks.avi
video.cfg
XO.de.txt
XO.exe
XO.nl.txt
XO.us.txt
mapZoom.jpg
```

FIG 16


USER INPUT DEVICE
14
16
18
SIGNAL PROCESSOR
I/O
24
22
DISPLAY
12
RAM
26
D,A,C
32
ROM
28
CPU
30
20
HAND-HELD ELECTRONIC DEVICE
10


ENTER
34
USER INPUT ?
YES
NO
36
DETERMINE MAGNITUDE OF INPUT SIGNAL
40
DETERMINE WHAT PORTION OR LEVEL OF DETAIL IS INDICATED BY THE INPUT SIGNAL
42
RETRIEVE SELECTED PORTION FROM COMPUTER READABLE MEDIUM
44
DISPLAY SELECTED PORTION
46
RETURN
38

FIG 17

09845818.043001